


No.	Component Name	Amount	ComponentNo.	No.	Component Name	Amount	ComponentNo.
1	HexagonScrew	16	PC000102SW	80	SteelBallSeat	1	PA000135
3	HexagonScrew	8	PC000004SW	&81	SteelBall	1	PA000005
&4	DownBallSeat(S303)	2	PA000009	&82	Pad	1	PB000092
#5	Oring	4	PB000108	&83	StarfruitSeat	1	PA000138
&6	UpBallSeat(S303)	2	PA000009	84	Starfruit	1	PA000142
&7	UpBallCover(A)	2	PA000133	85	ScrewOfDiaphragm	1	PC000082
&8	DownBallCover(A)	2	PA000134	&86	Diaphragm	1	PB000034
&9	Ball(S316)	4	PA000004	87	SeatOfPressureSpring	1	PA000145
#10	Pad	2	PB000006	88	SpringWasher	1	PC000042
11	Housing of Pump	2	PA000039	89	Nut	1	PC000169
12	SteelHexagonScrew	2	PC000176	90	PrseecureSpring	1	PA000108
13	Steel Washer	4	PC000057	91	CoverOfPressureSpring	1	PA000148
&14	Pad of Diaphragm	2	PA000059	92	CoverOfRegulator	1	PA000151
&15	Diaphram(U)	2	PB000029	93	Nut	1	PC000171
&17	Pad of Diaphragm	2	PA000059	94	ScrewForAdjust	1	PC000079
#18	Oring	2	PD000011	95	HexagonScrew	6	PC000100SW
19-28	ShaftCover-A Set	1	A16-19-28	96	Adapter	1	PA000155
20-28	ShaftCover-B Set	1	A16-20-28	97	90DegreesAdapter	1	PA000154
21-29	AxisSwitch Set	1	A16-21-29	98	MeterAdaper	1	PA000159
&22	ShaftOfDiaphragm	1	PA000114	&99	Meter	1	PA000163
#23	Pad	2	PB000001	100	DoubleThreadedMaleAdapter	1	02T02T
#24	Oring	2	PD000001	102-1	DoubleThreadedMaleAdapter	1	03T03T
32	HexagonScrew	4	PC000005SW				
#33	Abnormal Oring	1	PD000140				
#34	Abnormal Oring	1	PD000139				
35-45	Air-Valve Set	1	A16-35-45				
44	BodyOfCylinderBase	1	PA000143				
46	Pipe Set	2	PA000122T				
47	HexagonScrew	8	PC000100SW				
48	BufferPad	2	PD000056				
50	Silencer	1	PB000045				
51	AirPressureRoomOfPump	2	PA000172N				
52	HexagonBung	1	PC000413				
&53	SlitheryMass Valve	1	PB000334				
&54	IncludePly	1	PB000072				
55	DoubleThreadedMaleAdapter	1	X102X2				
56	AirRegulatorValve	1	DS-ABC02				
57	DoubleThreadedMaleAdapter	1	X103X2				
&58	DoubleThreadedSwitch	3	PA000167				
59	ThreeWayBronzeTube	1	PA000258				
*60	PressureStorage	1	DS-00-O				
&62	45DegreesSwitch	1	PA000168				
63	AdapterOfFlexibleTube	1	PA000257				
64	AdapterOfProtectiveTube	1	PA000233				
65	SpringOfProtective Tube	1	PA000109				
66	FlexibleTube	1	PB000100				
67	SuckerAdapter	1	03T04N				
68	SuckerDisk	1	PA000240				
69	FilteringScreen	1	PB000110				
&70	FineFilteringScreen	1	PA000244				
71	RetainingRing	1	PA000170				
72	ReturnTube	1	PB000099				
73	BodyOfStrainer	1	PA000179				
&74	Filter Set	1	PA000177				
75	DownCoverOfStrainer	1	PA000175				
76	Pad	1	PB000167				
77	Oring	1	PB000104				
78	DownBaseOfRegulator	1	PA000132				
&79	Spring	1	PA000107				

DSP03-AOBRF-02

Exploded View



("#"SPARE SEAL)

("&"Consumptive Parts Possible)


(A sign "*"means that component can be chosen or not.)

DSP03-AOBRF-02

Exploded View


("#"SPARE SEAL)
("&"Consumptive Parts Possible)

20-28|ShaftCover-B Set|1|A16-20-28




No.	Component Name	Amount	ComponentNo.
19	ShaftCover-A	1	PB000170
20	ShaftCover-B	1	PB000173
21	AxisSwitch	1	PA000150
#25	Oring	2	PD000023
#26	Oring	1	PD000050
#27	Oring	1	PD000054
#28	U-type Oring	3	PDAP0012
#29	Oring	1	PD000111


21-29|AxisSwitch Set|1|A16-21-29



19-28|ShaftCover-A Set|1|A16-19-28



35-45|Air-Valve Set|1|A16-35-45



No.	Component Name	Amount	ComponentNo.
&35	BodyOfSequential	1	PA000102
&36	PistonOfAirValve	1	PA000141
#37	U-type Oring	1	PDAP0023
#38	U-type Oring	2	PDR00016
&39	StartingCopperLatch	1	PA000112
40	CoverOfSequential-A	1	PD000080
41	CoverOfSequential-B	1	PB000021
#42	Oring	1	PD000035
43	HousingOfSequential	2	PA000117
45	HexagonScrew	4	PC000004SW